

Eco Smart

Replacing the rear wheel

Tools Required: Phillips Screwdriver, Long Nose Pliers, 10 mm wrench, Two 8 mm wrenches, Two 15 mm wrenches.

Note the sequence of the hardware before removing or replacing any parts from the unit.



1) With a Phillips screwdriver, remove the three (3) screws on the chain guard.



3) Push the chain tensioner down and remove the chain from the wheel sprocket.



4) With a long nose plier, remove the end cap from the brake cable. Do not throw the end cap.



5) With a 10 mm wrench, loose the brake cable anchor bolt and disconnect the cable.

6) With two (2) 8 mm wrenches, remove the cable guide bracket from the frame and brake plate. Keep all the hardware together.



7) With two (2) 15 mm wrenches, loosen the axle nuts from the wheel. Slide the wheel forward, remove the chain from the sprocket and remove the wheel. Note the sequence of the hardware.