

PAIRING A NEW REMOTE TO THE ZOOME AUTO-FLEX



1. Place the new remote in one hand and grasp the battery strap with the other.





2. Press and hold the "A" button on the new remote.



3. Remove the battery and continue to press the "A" button on the remote.



4. Continue to press the "A" button on the remote and install the battery. Continue to press the "A" button for 2 seconds after the battery is installed. Release the "A" button and now the remote is paired with the Zoome Auto-Flex.