






An easy to use crank-arm mounted quick stand, designed for 700c road bikes with Shimano® DURA-ACE, ULTEGRA or 105 crank-arm dimensions : $\leq 35 \times 80$ mm as shown below




ASSEMBLY



NOTE: FlashStand Slim is a two piece stand. Carefully slide its support legs out when deploying and try to avoid removing the support legs completely from crank arm holder sleeve. In case this happens, simply press the LOCK button and reinsert the support legs.




INSTALLATION



CAUTION

- FlashStand Slim is designed for 700c road bikes with Shimano® DURA-ACE, ULTEGRA or 105 crank-arm dimensions: $\leq 35 \times 80$ mm as shown.
- If support legs on FlashStand Slim become loose, tighten the bolts. Do not over tighten the bolts as this may damage the support legs.
- Remove any large or heavy bicycle accessories (handlebar bag, rack bag, large saddle bag, pannier bags, etc.) that may affect FlashStand Slim's proper function.
- Never exert force on the bike when using FlashStand Slim. Doing so may damage FlashStand Slim's support legs.
- Not recommended for use on grass, loose dirt, gravel, uneven or soft surfaces.



WARRANTY

2-year Warranty: All mechanical components against manufacturer defects only.

Warranty Claim Requirements

To obtain warranty service, you must have your original sales receipt. Items returned without a sales receipt will assume that the warranty begins on the date of manufacture. All warranties will be void if the product is damaged due to user abuse, overload, system alteration, modification, or used in any way not intended as described in this user's guide.

* The specifications and design are subject to change without notice.

Topeak products are available only from professional bicycle shops.

Please contact your nearest Topeak authorized bicycle dealer for any questions.

For customers in the USA, call: 1-800-250-3068 Website: www.topeak.com